

Part Description	Current Models							Item Number	Qty		
	140H	200H	340H	350H	200B	375B	500B				
Tank Mount Kit - 2250/500 Tank	x	x						05000075	1		
Copper Line, Pump to Preheater 8.5' - 250 Gallon	x	x						14070206	1		



Tank Mount Kits include mounting tubes, furnace support arms, hardware, pump harness and discharge copper.

Part Description	Current Models							Item Number	Qty		
	140H	200H	340H	350H	200B	375B	500B				
**Tank Mount Kit - 250/500 Gallon Tanks			x	x				05000076	1		
Copper Line, Pump to Preheater 8.5' - 250 Gallon			x	x				14070206	1		
Angle Brace (2 incl. in 05000076)			x	x				20352224	1		



Tank Mount Kit includes furnace support arms, angle braces, hardware and discharge copper. For use with EnergyLogic 250 and 500 gallon workbench tanks.

Part Description	Current Models							Item Number	Qty		
	140H	200H	340H	350H	200B	375B	500B				
Vent - 4 Inch Emergency Tank	x	x	x	x	x	x	x	20252174	1		



Install into aboveground storage tanks as a code requirement to help prevent the tank from becoming over-pressurized and possible rupturing if ever exposed to fire.

Part Description	Current Models							Item Number	Qty		
	140H	200H	340H	350H	200B	375B	500B				
Strainer Pan Assembly—10" x 20"	x	x	x	x	x	x	x	81010060	1		



Used as a funnel for draining and screening used oil from filters or components into the storage tank.

Part Description	Current Models							Item Number	Qty		
	140H	200H	340H	350H	200B	375B	500B				
Gauge - Tank, 24" 250 Gallon SW, 500 Gallon DW	x	x	x	x	x	x	x	20252140	1		
Gauge - Tank, 30" 250 Gallon DW	x	x	x	x	x	x	x	20252142	1		
Gauge - Tank, 36" 500 Gallon SW	x	x	x	x	x	x	x	06000728	1		



The tank gauge is used to monitor the fuel level in the tank.

Part Description	Current Models							Item Number	Qty		
	140H	200H	340H	350H	200B	375B	500B				
Switch-Low Fuel, 250 Gallon DW	x	x	x	x	x	x	x	14052236	1		
Switch-Low Fuel, 26" 250 Gallon SW, 500 Gallon DW	x	x	x	x	x	x	x	14052234	1		
Switch-Low Fuel, 35" 500 Gallon SW	x	x	x	x	x	x	x	04000379	1		
*Switch-Low Fuel, Adjustable up to 62"	x	x	x	x	x	x	x	14052235	1		
Switch-Float, Replacement 12' Cord	x	x	x	x	x	x	x	06000532	1		



Interrupts the operation of the unit when the fuel level is too low and prevents air and contaminants from entering the fuel system. Operates on the low voltage (24V) through the thermostat circuit.

Part Description	Current Models							Item Number	Qty		
	140H	200H	340H	350H	200B	375B	500B				
*Gauge Leak Detection, for Double Wall Tanks	x	x	x	x	x	x	x	06001084	1		

Part Description	Current Models							Item Number	Qty		
	140H	200H	340H	350H	200B	375B	500B				
*Alarm Kit, Tank Overfill	x	x	x	x	x	x	x	05000193	1		